



442710401452 © 04/ 2020, Signify Holding All rights reserved Printed in Poland Data subject to change without notice Keep for future reference: www.philips.com/lighting





To assure the lighting quality of this unique LED lighting concept there are a few instructions regading the maintenance of this LED luminaire:

1. Do not touch electronic components! Electronic components are under high voltage

Electronic components are ESD sensitive.

2. During installation or when maintaining the luminaire please use static free gloves to avoid marks on the luminaire.

 To remove dirt and spots use the following: Dust: only use micro fiber cloths Fingerprints, etc.: use a cleaner for synthetic materials with antistatic properties.

4. Do not stare into the LED light beam.

5. To avoid scratches and dirt on optical parts remove protective foil after installation. 6. The luminaire shall be installed by a qualified electrician and wired in accordance

with the lastest IEE electrical regulations or the nationak requirements.

7. The light source of this luminarie is not replaceable: when the light source reaches its end of life whole luminare shall be replaced.8. Driver insulation: Basic according to IEC 61847-1.







Printed in Poland Data subject to change without notice Keep for future reference: www.philips.com/lighting